

High Lifter Products, Inc.
780 N Professional Drive
Shreveport, LA 71105



(318) 524-2270
Fax (318) 524-2297

Polaris Ranger Front Lift Kit Installation Instructions

Read Before Installation!

This product is designed for use on ATVs on which additional ground clearance and fender clearance is desired. It is designed for utility type, slower-speed use on relatively flat terrain in deep mud or snow. Although we have many thousands of satisfied lift kit customers and over 400 franchised dealers selling and installing lift kits, purchasers should be aware that use of this product may increase the frequency of required maintenance, part wear, and will raise the center of gravity on your ATV increasing risk of roll-over on side hills, ditches or other steep terrain.

We recommend that wider tires and/or wheel spacers be used to achieve a wider stance and to improve stability of the ATV. Riders should be advised that the handling characteristics of a taller ATV are different and require extra care when riding on side hills or off-camber situations. If you further raise the center of gravity by adding heavy loads to racks or seats, the ATV must be operated with care, at slower speeds or on relatively flat ground.

Operation of an ATV with or without a lift kit, while or shortly after consuming alcohol or drugs, subjects the rider to the risk of serious bodily harm or possible death. This is compounded if the rider does not wear an approved helmet and other safety gear. High Lifter urges that all approved safety gear be worn when riding an ATV.

If this is not what you expected, or is not consistent with your intended use, you should return the product immediately to the seller, before installation, for a refund of the purchase price; less any fees. After installation, product is warranted for 90 days for defects in workmanship and materials. Warranty is limited to refund of the purchase price or replacement of the kit, at the seller's option.

This lift kit contains the following parts:

Small Round Bracket	2
Large round Bracket	2
Pages of Diagrams	3
Pages of Instructions	2

WARNING: The McPherson struts on the front of this ATV are preloaded and are under extreme pressure. A spring compressor is required for the installation. Most local auto parts stores carry spring compressors for around \$25 for a very basic model. If you do not have experience working with this type of tool, we strongly recommend that an authorized factory dealer install this lift kit. This job will be much easier if you will remove your front plastic, which will allow you to pull the strut straight out from the top.

Front Lift


- 1) Place jack under center of ATV front end and lift until front wheels clear the ground. Be careful to support ATV properly so that it is secure, but so that the A-arms and shocks can drop about 2".

Warning: DO NOT let the A-arms drop to full extension. If you allow the A-arms to drop to full extension, the axle will possibly come out of the hub. If this happens, you will spend two more hours fixing this. For those of you that got ahead of yourself and are already facing this dilemma, don't panic. Get a Polaris repair manual or have your local Polaris dealer correct this problem.


- 2) Remove front wheels and boot guards.
- 3) Using a spring compressor, compress the front struts. Take the top nut off, loosen the bottom two bolts and slide the strut out. **Tip:** (When sliding the strut out, be sure it is completely collapsed. This will make it easier to get out.) **For the Novice:** When you first start to pull the strut out it will want to extend. Once several inches of the bottom shaft are exposed, you can hold the bottom and push the top back down. You may have to do this several times in order to get the strut out of the socket.
- 4) Drop bracket "A" into the bottom of the strut socket and place bracket "B" on the top lip.
- 5) Place the factory washer over bracket "B" and slide the strut back into the socket. You may need to use a screwdriver between the springs to push the bottom of the strut down into the socket. (Note: Make sure the bottom of the strut is resting on the top of bracket "A". You can feel bracket "A" from underneath, to verify it's touching the bottom of the strut. DO NOT put your finger up into the hole.)
- 6) Tighten the bottom two bolts and reinstall the top nut on the top of the strut. (Be sure to reattach the brake line to the top bolt if you took it off.)
- 7) After all bolts have been tightened, loosen and remove the spring compressor.
- 8) Repeat this process on the other side.
- 9) Install the wheels, torque wheel lug nuts to manufacturer's specifications, lower and remove jack. Check for clearance problems or misalignment.

Parts List

Bracket A-2



Bracket B-2



Installation Diagrams

